

Warning! Important Information

1. Do not immerse unit in liquid or allow liquid to enter unit.
2. Do not use while bathing or in a shower.
3. Do not place or store unit where it can fall or be pulled into a tub or sink.
4. Never operate this unit if it is not working properly, or if it has been dropped, damaged, or dropped into water.
5. The unit should be situated away from heat sources such as direct sunlight, radiators, heat registers, stoves, vehicles, and other heat-producing appliances.
6. Do not operate under a blanket or pillow.
7. Do not try servicing the unit.
8. Do not try disassembling the unit. High voltage inside.

Caution!

Pacemaker patients, people with a history of respiratory problems, and heart or lung disease should consult a physician prior to using this product.

The ionic technology used by this unit produces immeasurable amounts of ozone as a by-product. This unit complies with U.S. government limits for acceptable levels of ozone (less than 50 parts per billion of air circulated by the unit).

FCC Compliance Information

This unit complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

PORTABLE PERSONAL MINI AIR PURIFIER

Rechargeable



InvisiClean IC-103 User Manual

**Must Read Before Use
Please keep this manual
for future reference**

Package Contents

Mini Air Purifier	x 1
User Manual	x 1
Cord	x 1
USB Cord	x 1

Specification

Model No	IC-103
Product Dimension	1.8 L x .95 W x 2.7 H in
Product Weight	1.4 oz
Battery	Lithium battery 400 mA / 3.6V
Battery life cycle	300 cycles

Charging

Your Personal Air purifier contains a rechargeable lithium battery (3.6V, 400 mAh). Under normal use, you will experience about 240 hours of run time on one charge. (or 8 hours of use with the fan on).

Please follow these directions to charge your device:

1. Ensure the power is OFF.
2. Plug small end of the included USB cable into the device's USB jack. Plug the large end of the USB cable into any powered USB port (e.g. computer, power bank, etc.) The indicator light will turn BLUE when charging.
3. It takes about 2 hours to fully charge. The indicator will turn off when fully charged.

Charging and use

1. If you are charging and turn the unit on, the green and blue LEDs will both be lit.
2. You may turn the switch in the ON position while plugged in and charging through the USB port. This will allow you to clean the air while charging the device.
3. You get the best performance when the device is on and plugged in.

How to use

1. Turn your device on by sliding switch to MODE1/ MODE2.



MODE 1 Ion ONLY

A steady stream of negative ions will be emitted from the ionizer, creating a clean zone of healthier air within your breathing space. A green light will blink to indicate that power is on and the unit is cleaning your air.

MODE 2 Ion + FAN

Both ionizer and a mini fan will turn ON. The mini fan increases the effectiveness of the negative ions using airflow.

2. You may use the device in following ways:
 - Worn around your neck with included cord
 - Placed on a nearby table
 - Clipped onto your shirt
3. Slide the switch to OFF position when you are finished using the device.

Notice

Do not store this device in its storage box when the switch is ON. Do not touch the ionizer emitter, this will reduce the life of ionizer emitter brush.